

6SB218 or 8SB218 6 Foot or 8 Foot 2 Shelf Step Bench Assembly Instructions

Kit Contents:

3-Leg Assemblies
2-18"x72" or 92" Shelves
1-1"x4"x6" or 8" Front Leg Brace Board
1- Back Assembly
42-2" Screws

Back Assembly

Leg Assembly



Front
Brace Board

Step 1: Unload the pallet and sort the parts. All three leg assemblies are the same and line up the same way. Stand 2 leg assemblies upright and 72 or 92 inches apart. Attach the back assembly to the bottom corner of the legs making sure the corners are flush. **See Photo** Insert 4 screws per end into the pre-drilled holes of the back brace and attach top & bottom.

Step 2: Place the top shelf on top of the leg assemblies and slide it back until it is flush with the back leg assembly. Then place the center leg assembly into the cleats under the center of the shelf. Secure it to the back brace with 4 screws making sure the leg assembly is straight. There are no pre-drilled holes for that leg assembly. Attach the top shelf by inserting screws into the pre-drilled holes in the shelf top.

Step 3: Place the second shelf onto the bottom leg extensions and attach with 4 screws per side and center into the pre-drilled holes in the shelves.

Step 4: Flip the bench over to allow access under the lower shelf. Lay the brace board 2" from the bottom of the legs and across the front leg assemblies. **See Photo** Attach with 2" screws, one through the brace board and into each leg.

This display is made of natural white cedar decking. If used outside it will turn gray over two seasons. You can clean the display by power washing. It can also be stained or sealed with a semi-transparent exterior deck sealer. We recommend Cabot 3060 because of it's UV protection.



For questions or ordering information contact
Bench System's customer service at 1-800-231-7072
www.benchsystems.com